


WATTNODE[®] PLUS and WATTNODE[®] LOGGER for LONWORKS[®]

Electric Power Meter – Installation Manual



WattNode Plus for LonWorks Models

WNC-3Y-208-FT10
WNC-3Y-400-FT10
WNC-3Y-480-FT10
WNC-3Y-600-FT10
WNC-3D-240-FT10
WNC-3D-400-FT10
WNC-3D-480-FT10

WattNode Revenue for LonWorks Models

RWNC-3Y-208-FT10
RWNC-3Y-400-FT10
RWNC-3Y-480-FT10
RWNC-3Y-600-FT10
RWNC-3D-240-FT10
RWNC-3D-400-FT10
RWNC-3D-480-FT10

Note: all of the above models are available as Logger versions by adding “-L” to the model number.



Socomec Group

www.ctlsys.com

Contents

1	Precautions	3
1.1	Symbols	3
2	Overview	3
2.1	Additional Literature	3
2.2	Electrical Service Types	4
3	Installation	7
3.1	Installation Checklist	7
3.2	Mounting	7
3.3	Connect Voltage Terminals	7
3.4	Connect Current Transformers	8
3.5	Connect the Output Signals	9
3.6	LonWorks FT-10 Network Wiring	9
4	Operation	10
4.1	Initial Configuration	10
4.2	LonWorks Service LED	10
4.3	Monitoring	11
4.4	Maintenance and Repair	11
5	Specifications	11
5.1	Accuracy	11
5.2	Measurement	11
5.3	Electrical	12
5.4	Certifications	13
5.5	Environmental	13
5.6	Mechanical	13
5.7	FCC Information	14
5.8	Warranty	15
5.9	Limitation of Liability	15

1 Precautions

- Only qualified personnel or **licensed electricians** should install the WattNode meter. The mains voltages of 120 to 600 Vac can be lethal!
- Follow all applicable local and national electrical and safety codes.
- The terminal block screws are **not** insulated. Do not contact metal tools to the screw terminals if the circuit is live!
- Verify that circuit voltages and currents are within the proper range for the meter model.
- Use only UL Listed or UL Recognized current transformers (CTs) with built-in burden resistors, that generate 0.333 Vac (333 millivolts AC) at rated current. **Do not use current output (ratio) CTs such as 1 amp or 5 amp output CTs: they will destroy the meter and may create a shock hazard.**
- Protect the line voltage conductors to the meter with fuses or circuit breakers (not needed for the neutral or ground wires). See **3.3.1** below.
- Disconnect equipment from HAZARDOUS LIVE voltages before access.
- If the meter is not installed correctly, the safety protections may be impaired.

1.1 Symbols



Read, understand, and follow all instructions including warnings and precautions before installing and using the product.



Potential Shock Hazard from Dangerous High Voltage.



Functional ground; should be connected to earth ground if possible, but is not required for safety grounding.



UL Listing mark for U.S.A. and Canada.



FCC Mark. This logo indicates compliance with part 15 of the FCC rules.



Complies with the regulations of the European Union for Product Safety and Electro-Magnetic Compatibility.

- Low Voltage Directive – EN 61010-1:2010 (3rd Edition)
- EMC Directive – EN 61326-1:2006 Industrial Locations



This indicates an AC voltage.

2 Overview

Congratulations on your purchase of the WattNode® for LONWORKS® or WattNode® Revenue for LONWORKS® watt/watt-hour transducer (meter). It is designed for use in demand side management (DSM), submetering, energy monitoring, billing and renewable energy applications. The WattNode meter communicates on a two-wire bus using the LonTalk® protocol.

The WattNode Revenue version meets the ANSI C12.1 standard for revenue metering when used with IEEE C57.13 class 0.6 current transformers, such as the Accu-CT®.

WattNode for LONWORKS models are LonMark® certified, providing assurance of interoperability.

2.1 Additional Literature

See the Continental Control Systems, LLC website (<https://ctlsys.com>) for product pages, datasheets, and support pages for all WattNode meter models and current transformers. Each WattNode model has an **Operating and Reference Guide** with detailed information on the available measurements and interface.




Figure 1: WattNode Wiring Diagram

2.2 Electrical Service Types

Electrical Service (or Load) Types	Line-to-Neutral (Vac)	Line-to-Line (Vac)	Meter Service Type	Meter Powered by
1 Phase 2 Wire 120V with neutral	96 – 138	n.a.	3Y-208	N and ϕA
1 Phase 2 Wire 230V with neutral (non-N.A.)	184 – 264	n.a.	3Y-400	N and ϕA
1 Phase 2 Wire 277V with neutral	222 – 318	n.a.	3Y-480	N and ϕA
1 Phase 2 Wire 208V no neutral	n.a.	166 – 276	3D-240	ϕA and ϕB
1 Phase 2 Wire 240V no neutral	n.a.	166 – 276	3D-240	ϕA and ϕB
1 Phase 3 Wire 120V/240V with neutral	96 – 138	166 – 276	3Y-208	N and ϕA
			3D-240	ϕA and ϕB
3 Phase 3 Wire Delta 208V no neutral	n.a.	166 – 276	3D-240	ϕA and ϕB
3 Phase 3 Wire Delta 400V no neutral (non-N.A.)	n.a.	320 – 460	3D-400	ϕA and ϕB
3 Phase 3 Wire Delta 480V no neutral	n.a.	384 – 552	3D-480	ϕA and ϕB
3 Phase 4 Wire Wye 120V/208V with neutral	96 – 138	166 – 276	3Y-208	N and ϕA
			3D-240	ϕA and ϕB
3 Phase 4 Wire Delta 120/208/240V with neutral	96 – 138	166 – 276	3D-240	ϕA and ϕB
3 Phase 4 Wire Wye 230V/400V with neutral (non-N.A.)	184 – 264	320 – 460	3Y-400	N and ϕA
			3D-400	ϕA and ϕB
3 Phase 4 Wire Wye 277V/480V with neutral	222 – 318	384 – 552	3Y-480	N and ϕA
			3D-480	ϕA and ϕB
3 Phase 4 Wire Delta 240/415/480V with neutral	222 – 318	384 – 552	3D-480	ϕA and ϕB
3 Phase 4 Wire Wye 347V/600V with neutral	278 – 399	480 – 690	3Y-600	N and ϕA


Table 1: WattNode Models

Table 1 above lists the WattNode models and common circuit types. In the “Electrical Service Types” column, when two voltages are listed with a slash between them, they indicate the line-to-neutral / line-to-line voltages. The “Line-to-Neutral” and “Line-to-Line” columns show the operating ranges for the WattNode meters. “non-N.A.” refers to non-North American electrical services.

Connect the line voltages to the meter inputs as shown in the following figures for each service type. See **Figure 1** above for an overview.


2.2.1 Single-Phase Two-Wire with Neutral

This is a common residential and branch circuit connection. You may monitor up to three single-phase circuits with one meter by also using the ϕB and ϕC inputs.




2.2.2 Single-Phase Two-Wire, No Neutral

This circuit occurs in residential (commonly 120/240 Vac) and some commercial applications. The meter is powered from the ϕA and ϕB terminals. We recommend connecting the **N** terminal to ground to provide a clean voltage reference for the measurement circuitry (no current will flow through this terminal).



2.2.3 Single-Phase Three-Wire with Neutral


This is a common North American residential service at 120/240 Vac.



2.2.4 Three-Phase Three-Wire Delta, No Neutral


This is common in commercial and industrial settings. In some cases, the service may be four-wire wye while the load is three wire (no neutral).

Occasionally, a load will only be connected to two of the three lines (say **L1** and **L2**). For this case, connect the two active lines to the ϕA and ϕB terminals and connect two CTs for the two lines.



2.2.5 Three-Phase Four-Wire Wye with Neutral

This is a common commercial and industrial service.




2.2.6 Three-Phase Four-Wire Delta with Neutral (Wild Leg)

The uncommon four-wire delta electrical service is a three-phase delta service with a center-tap on one of the transformer windings to create a neutral for single-phase loads.

The high-leg or phase with the higher voltage as measured to neutral has traditionally been designated “Phase B”. A change to the 2008 NEC now allows the high leg of a four-wire three-phase delta service to be labeled as the “C” phase instead of the “B” phase. The WattNode meter will work correctly with the high-leg connected to ϕA , ϕB , or ϕC .

See the web article https://ctlsys.com/support/four_wire_delta_circuits/ for more information.



2.2.7 Grounded Leg Service

In rare cases with delta services or single-phase two-wire services without neutral, one of the phases may be grounded.

The WattNode meter will correctly measure services with a grounded leg, but the measured voltage and power for the grounded phase will be zero. Also, this type of service may result in unusual power factors.

For more information, see https://ctlsys.com/support/corner-grounded_delta_circuits/.

3 Installation

3.1 Installation Checklist

See the sections referenced below for installation details.

- Turn off power** before making line voltage connections.
- Mount the meter (see **3.2**).
- Connect circuit breakers or fuses and disconnects (see **3.3.1**).
- Connect the line voltage wires to the meter's green terminal block (see **3.3.2**).
- Mount the CTs around the line conductors. Make sure the CTs face the **source** (see **3.4**).
- Connect the twisted white and black wires from the CTs to the black terminal block on the meter, matching the wire colors to the white and black dots on the meter label (see **3.4.1**).
- Check that the CT phases match the line voltage phases (see **3.4**).
- Record the CT rated current for each CT, because it will be required during commissioning.
- Connect the output terminals of the meter to the monitoring equipment (see **3.5**).
- Check that all the wires are securely installed in the terminal blocks by tugging on each wire.
- Turn on power to the meter.
- Verify that the LED indicates correct operation (see **4.2**).

3.2 Mounting

- Protect the meter from temperatures below -30°C (-22°F) or above 55°C (131°F), excessive moisture, dust, salt spray, or other contamination, using a NEMA rated enclosure if necessary. The meter requires an environment no worse than pollution degree 2 (normally only non-conductive pollution; occasionally, a temporary conductivity caused by condensation).
- The meter must be installed in an electrical service panel or an enclosure.
- **Do not** use the meter as a drilling guide; the drill chuck can damage the screw terminals and metal shavings may fall into the connectors.

The meter has two mounting holes spaced 5.375 in. (137 mm) apart (center-to-center). These mounting holes are normally obscured by the detachable screw terminals. Remove the screw terminals to mark the hole positions and mount the meter.

Self-tapping #8 sheet metal screws are included. Don't over-tighten the screws, as long-term stress on the case can cause cracking.

3.3 Connect Voltage Terminals

3.3.1 Circuit Protection

The WattNode meter is considered "permanently connected equipment" and requires a disconnect means (circuit breaker, switch, or disconnect) and overcurrent protection (fuse or circuit breaker).

The meter only draws 10-30 milliamps, so the rating of any switches, disconnects, fuses, or circuit breakers is determined by the wire gauge, the mains voltage, and the current interrupting rating required.

- The disconnect or circuit breaker must be clearly marked, suitably located, and easily reached.
- Use circuit breakers or fuses rated for 20 amps or less.
- Use ganged circuit breakers when monitoring more than one line voltage.
- The circuit breakers or fuses must protect the mains terminals labeled **ØA**, **ØB**, and **ØC**. In the rare cases where neutral has overcurrent protection, then the overcurrent protection device must interrupt both neutral and the ungrounded conductors simultaneously.
- The circuit protection / disconnect system must meet IEC 60947-1 and IEC 60947-3, as well as all national and local electrical codes.

3.3.2 Line Wiring

- **Always turn off power** before connecting the line voltage inputs to the meter.
- For the line voltage wires, CCS recommends 18 to 12 AWG stranded wire, type THHN, MTW, or THWN, 600 V.

- Use copper conductors only. The screw terminals are only rated for copper wire.
- Do not place more than one wire in a screw terminal; use additional wire nuts or terminal blocks if needed.
- Verify that the line voltages are in the range of the line-to-line ϕ - ϕ and line-to-neutral ϕ -N values printed in the white box on the front label.

The screw terminals handle wire up to 12 AWG. Connect each voltage line to the green terminal block as shown in **Figure 1** above. After the voltage lines have been connected, make sure both terminal blocks are fully seated in the meter.

Connect each line voltage to the appropriate phase; also connect ground and neutral (if applicable). The neutral connection "N" is not required on delta models (3D-240, 3D-400, and 3D-480), but we recommend connecting it to ground if neutral is not present.

3.3.3 Grounding

The WattNode uses a plastic enclosure, insulation, and internal isolation barriers instead of protective earthing. The ground terminal on the green screw terminal block is a functional ground, designed to improve the measurement accuracy and noise immunity. If necessary, this terminal may be left disconnected on wye models (-3Y).

3.4 Connect Current Transformers

To meet the UL listing requirements, the meter must be used with UL Listed or the following UL Recognized current transformer models. These all generate 0.33333 volts AC at rated current.

ACT-0750-xxx	CTS-2000-xxxx	CTT-1000-xxx
CTL-1250-xxx	CTB-WxL-xxxx	CTT-1250-xxx
CTM-0360-xxx	CTT-0300-xxx	CTRC-yyyyy-xxxx
CTS-0750-xxx	CTT-0500-xxx	
CTS-1250-xxx	CTT-0750-xxx	

- "xxx" indicates the full scale current rating.
- "WxL" indicates the opening width (W) and leg length (L) in inches.
- "dddd" indicates the opening diameter of the loop for flexible Rogowski CTs.
- "yyyyy" indicates the opening size in mils (thousandths of inches).

See the web article https://ctlsys.com/selecting_current_transformers/ for information on selecting appropriate current transformers (CTs).

- **WARNING:** To reduce the risk of electric shock, always open or disconnect circuit from power-distribution system or service of the building before installing or servicing current transformers.
- **Do not** use ratio or current output CTs such as 1 amp or 5 amp output models!
- The CTs are not suitable for Class 2 wiring methods and must be treated as Class 1 wires.
- Secure each current transformer and route the lead wires so that they do not directly contact live terminals or buses.
- Do not install current transformers where they would: 1) exceed 75 percent of the wiring space of any cross-sectional area within the equipment, 2) would block ventilation openings, or 3) would be in an area of breaker arc venting.
- See the CT datasheets for the maximum input current ratings.
- Be careful to match the CTs with the voltage phases. Make sure the ϕ A CT is measuring the current on the same phase being monitored by the ϕ A voltage input, and the same for phases B and C. Use the supplied colored labels or colored tape to identify the CT leads.
- To minimize measurement noise, avoid extending the CT wires beyond 50 feet (15 meters), especially in noisy environments. If it is necessary to extend the wires, use twisted pair wire 22 to 14 AWG, rated for 300 V or 600 V (not less than the service voltage) and shielded if possible.
- Find the source arrow or label "THIS SIDE TOWARD SOURCE" on the CT and face/point toward the source of current.
- OPTIONAL: if you see spurious readings on unused phases, jumper the unused CT inputs: for each unused CT, connect a short wire from the terminal marked with a white dot to the terminal marked with a black dot.

Install the CTs around the conductor to be measured and connect the CT leads to the meter as shown in **Figure 1** above.

Split-core CTs can be opened for installation around a conductor. A nylon cable tie may be secured around the CT to prevent inadvertent opening.

CTs are directional. If they are mounted backwards or with their white and black wires swapped the measured power will be negative.

When installing WattNode Revenue models, be sure to only use IEEE C57.13 class 0.6 current transformers, such as the Accu-CT; other CTs are less accurate and may not provide revenue accuracy. Contact sales for more information on appropriate CTs.

3.4.1 CT Wiring

The current transformers connect to the six position black screw terminal block. Connect the white and black CT wires to the meter terminals marked **ØA CT**, **ØB CT**, and **ØC CT** (see **Figure 1** above). Excess length may be trimmed from the wires if desired. Connect each CT with the white wire aligned with the white dot on the label, and the black wire aligned with the black dot. Note the order in which the phases are connected, as the line voltage phases **must** match the current phases for accurate power measurement.


3.5 Connect the Output Signals

- The meter outputs are electrically isolated from dangerous voltages.
- If the output wiring is near line voltage wiring, use wires or cables with a 300 V or 600 V rating (not less than the service voltage).
- If the output wiring is near bare conductors, it should be double insulated or jacketed.
- You may install two wires into each screw terminal by twisting the wires together, inserting them into terminal, and securely tightening. Note: a loose wire can disable an entire network section.
- Use twisted-pair cable (unshielded or shielded) to prevent interference. See **LonWorks FTT10 Cables** (https://ctsys.com/support/lonworks_ftt10_cables/) for details.

3.6 LonWorks FT-10 Network Wiring

CCS recommends that an experienced LonWorks network installer be consulted for network design, particularly for the areas of topology, repeaters, wiring, and termination. See the **Operating and Reference Guide** for more details on LonWorks networks.

- The meter's **FT10** outputs are completely isolated from all dangerous voltages, so you can connect them at any time with the meter powered.
- Connect the network wiring to the two circuit black terminal block labeled **FT10** and tighten the screws. The FT-10 twisted pair network is not polarized, so either network wire can be connected to either screw terminal.
- FT-10 wiring is daisy-chained between meters, with up to 127 devices per subnet. The protocol has limits on the total wire length as well as stub lengths, so see LonWorks FT-10 documentation for details and recommended cabling.



- Once the meter is connected to the network and power is applied, configure it on the LonWorks network using any of the following:
- Enter the meter information into the network management software and press the service pin (button) on the meter when prompted. The service pin is located on the side of the case to the left of the service LED.
- Record the meter's Neuron ID and enter into the network management software.
- Scan the network for unconfigured devices.

4 Operation

4.1 Initial Configuration

Generally, the network integrator will remotely configure the WattNode meter and the variables. For details on configuring the WattNode meter, see the appropriate [Operating and Reference Guide](#) for your model.

The meter does not include a display, so it is not possible to configure or monitor the meter directly, other than pressing the service pin (button) to identify the meter on the LonTalk network.


At a minimum, the **CtAmps** must be programmed with the rated amps of the attached current transformers for correct measurements.

4.2 LonWorks Service LED

The LonWorks service LED indicates the network configuration status of the WattNode. The LED should always light while the service button (on the side of the case below the LED) is being pressed: this can test that the WattNode is powered.

Many problems can be diagnosed by observing the service LED. The figures below shows the different behaviors of the WattNode service LED after power up. During normal operation, after the initial power up and network configuration, the LED should remain OFF. During some network management actions, the service LED may light or flash until the action is complete. The following terms describe the various states of the WattNode.

4.2.1 Unconfigured



The WattNode is operating properly, but has not yet been configured (installed) by network management software. The LED will flash continuously.

4.2.2 Configured



The WattNode is operating properly and has been configured by network management software. The LED will flash briefly when power is first applied, but otherwise will stay off unless you press the service button.

4.2.3 Internal Error



A solid red LED indicates that the WattNode meter is not functioning correctly and must be returned for service.

4.2.4 Other

Any other LED pattern may be an internal error, indicating the WattNode needs to be serviced. Before returning the WattNode, try cycling power and carefully observing the LED. If possible, note the LED behavior, as this will help with diagnostics.

4.3 Monitoring

The meter does not include a display or buttons, so it is not possible to operate the meter directly. The following is a brief overview of the possible remote monitoring.

The LONWORKS models communicate measurements over the various types of networks. The measurements include: energy, power, voltage, current, line frequency, power factor, reactive power, and demand.

In order to monitor and configure networked WattNode models, you will need an appropriate monitoring solution, either standalone or PC software.

See the [Operating and Reference Guide](#) for a complete list of network accessible variables.

4.4 Maintenance and Repair

The WattNode meter requires no maintenance. It is not user serviceable and there are no replaceable parts except the pluggable screw terminals and the battery on Logger models. There are no diagnostic tests that can be performed by the user, other than checking for errors via the LonTalk interface or the service LED.

In the event of any failure, the meter must be returned for service (contact CCS for an RMA). For a new installation, follow the troubleshooting instructions in the [Operating and Reference Guide](#) before returning the meter for service, to ensure that the problem is not connection related.

If desired, to clean the meter, disconnect power and then use a dry or damp cloth or a brush.

4.4.1 WattNode Logger Battery Replacement

- The WattNode Logger for LonWorks meter contains a lithium battery to maintain the date and time during power failures. This battery can be replaced by the user. See the [Operating and Reference Guide](#) for details.
- Replace battery with Panasonic, part number BR2325 only. Use of another battery may present a risk of fire or explosion.

5 Specifications

The following is a list of basic specifications. For extended specifications, see the [Operating and Reference Guide](#).

5.1 Accuracy

The following accuracy specifications do not include errors caused by the current transformer accuracy or phase angle errors. "Rated current" is the current that generates a CT output voltage of 0.33333 Vac.

Normal Operation:

- **Line voltage:** -20% to +15% of nominal
- **Power factor:** 1.0
- **Frequency:** 48 - 62 Hz
- **Ambient Temperature:** 23°C ± 5°C
- **CT Current:** 5% - 100% of rated current

Accuracy: ±0.5% of reading

For accuracy at other conditions, see the reference guide.

WattNode Revenue Models:

- Meets the ANSI C12.1-2008 standard for revenue metering when used with IEEE C57.13 class 0.6 current transformers.

5.2 Measurement

Update Rate: 5.0 seconds. Internally, all measurements are performed at this rate.

Start-Up Time: ~5.0 seconds. The meter starts measuring power/energy and reporting measurements this long after AC voltage is applied.

Default CT Phase Angle Correction: 0.0 degrees.

5.3 Electrical

Meter Service Type	Nominal Vac Line-to-Neutral	Nominal Vac Line-to-Line	Phases	Wires
3Y-208	120	208–240	1 or 3	2 - 4
3Y-400	230	400	1 or 3	2 - 4
3Y-480	277	480	1 or 3	2 - 4
3Y-600	347	600	1 or 3	2 - 4
3D-240	120*	208–240	1 or 3	2 - 4
3D-400	230*	400	3	2 - 4
3D-480	277*	480	3	2 - 4

Table 2: WattNode Model Service Types

*Note: the delta models have an optional neutral connection that may be used for measuring wye circuits. In the absence of neutral, voltages are measured with respect to ground. Delta WattNode models use the phase A and phase B connections for power.

Over-Voltage Limit: 125% of nominal Vac. Extended over-voltage operation can damage the WattNode and void the warranty.

Over-Current Limit: 120% of rated current. Exceeding 120% of rated current will not harm the WattNode meter but the current and power will not be measured accurately.

Maximum Surge: 4kV according to EN 61000-4-5, 6kV for WattNode Revenue models.

Power Consumption: The following table shows maximum volt-amperes, the power supply ranges, typical power consumption, and typical power factors with all three phases powered at nominal line voltages. The power supply consumes most of the total power, while the measurement circuitry draws 1-10% of the total (6-96 milliwatts per phase, depending on the model). Due to the design of the power supply, WattNode meters draw slightly more power at 50 Hz.

Meter Service Type	Real Power (60 Hz)	Real Power (50 Hz)	Power Factor	Rated VA ⁽¹⁾	Power Supply Range (Vac)	Power Supply Terminals
3Y-208	1.5 W	1.8 W	0.79	4 VA	96 – 138	N and ϕA
3Y-400	1.6 W	1.8 W	0.73	4 VA	184 – 264	N and ϕA
3Y-480	1.6 W	2.0 W	0.69	4 VA	222 – 318	N and ϕA
3Y-600	1.0 W	1.3 W	0.76	4 VA	278 – 399	N and ϕA
3D-240	1.2 W	1.5 W	0.70	4 VA	166 – 276	ϕA and ϕB
3D-400	1.1 W	1.4 W	0.67	3 VA	320 – 460	ϕA and ϕB
3D-480	1.2 W	1.6 W	0.70	3 VA	384 – 552	ϕA and ϕB

Table 3: Power Consumption and Supply Voltage

⁽¹⁾Note: The **Rated VA** is the maximum at 115% of nominal Vac at 50 Hz. This is the same as the value that appears on the front label of the meter.

Maximum Power Supply Voltage Range: -20% to +15% of nominal (see table above). For the 3D-240 service, this is -20% of 208 Vac (166 Vac) to +15% of 240 Vac (276 Vac).

Operating Frequencies: 50/60 Hz

Measurement Category: CAT III

Measurement category III is for measurements performed in the building installation or on the load side of the main service breaker. Examples are measurements on distribution boards, circuit-breakers, wiring, including cables, bus-bars, junction boxes, switches, socket-outlets in the fixed installation, and equipment for industrial use and some other equipment, for example, stationary motors with permanent connection to the fixed installation.

The line voltage measurement terminals on the meter are rated for the following CAT III voltages (these ratings appear on the front label):

Meter Service Type	CAT III Voltage Rating
3Y-208 3D-240	240 Vac
3Y-400 3D-400	400 Vac
3Y-480 3D-480	480 Vac
3Y-600	600 Vac

Table 4: WattNode CAT III Ratings

Current Transformer Inputs:

Nominal Input Voltage (At CT Rated Current): 0.33333 Vac RMS

Absolute Maximum Input Voltage: 5.0 Vac RMS

Input Impedance at 50/60 Hz: 23 kΩ

5.4 Certifications

Safety:

- **UL 61010-1 (3rd Edition)**
- **CAN/CSA-C22.2 No. 61010-1-04**
- **IEC 61010-1:2010 (3rd Edition)**
- **Immunity:** EN 61326: 2006 (Industrial Locations)
- **Electrostatic Discharge:** EN 61000-4-2
- **Radiated RF Immunity:** EN 61000-4-3
- **Electrical Fast Transient / Burst:** EN 61000-4-4
- **Surge Immunity:** EN 61000-4-5
- **Conducted RF Immunity:** EN 61000-4-6
- **Voltage Dips, Interrupts:** EN 61000-4-11

Emissions:

- **FCC Part 15, Class B**
- **EN 55022:** 1994, Class B

5.5 Environmental

Operating Temperature: -30°C to +55°C (-22°F to 131°F)

Altitude: Up to 2000 m (6560 ft)

Operating Humidity: non-condensing, 5 to 90% relative humidity (RH) up to 40°C, decreasing linearly to 50% RH at 55°C.

Pollution: POLLUTION DEGREE 2 - Normally only non-conductive pollution; occasionally, a temporary conductivity caused by condensation must be expected.

Indoor Use: Suitable for indoor use.

Outdoor Use: Suitable for outdoor use if mounted inside an electrical enclosure (Hammond Mfg., Type EJ Series) rated NEMA 3R or 4 (IP 66).

5.6 Mechanical

Enclosure: High impact, ABS/PC plastic

Flame Resistance Rating: UL 94V-0, IEC FV-0

Size: 6.02 in. x 3.35 in. x 1.50 in. (153 mm x 85 mm x 38 mm)

Connectors: Euroblock pluggable terminal blocks

Green: up to 12 AWG (2.5 mm²), 600 V

Black: up to 12 AWG (2.5 mm²), 300 V

5.7 FCC Information

This equipment has been tested and complies with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The FCC limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

5.8 Warranty

The WattNode for LonWorks meters sold by Continental Control Systems, LLC (CCS) are guaranteed against defects in material and workmanship for a period of five years from the original date of shipment. CCS's responsibility is limited to repair, replacement, or refund, any of which may be selected by CCS at its sole discretion. CCS reserves the right to substitute functionally equivalent new or serviceable used parts.

WattNode Logger models include a lithium battery to preserve the date and time during power failures. CCS will replace or provide a replacement battery at no charge if the battery fails within five years from the original date of shipment.

This warranty covers only defects arising under normal use and does not include malfunctions or failures resulting from: misuse, neglect, improper application, improper installation, water damage, acts of nature, lightning, product modifications, alterations or repairs by anyone other than CCS.

Except as set forth herein, CCS makes no warranties, expressed or implied, and CCS disclaims and negates all other warranties, including without limitation, implied warranties of merchantability and fitness for a particular purpose.

5.9 Limitation of Liability

In no event shall CCS be liable for any indirect, special, incidental, punitive or consequential damages of any kind or nature arising out of the sale or use of its products whether such liability is asserted on the basis of contract, tort or otherwise, including without limitation, lost profits, even if CCS has been advised of the possibility of such damages.

Customer acknowledges that CCS's aggregate liability to Customer relating to or arising out of the sale or use of CCS's products, whether such liability is asserted on the basis of contract, tort or otherwise, shall not exceed the purchase price paid by Customer for the products in respect of which damages are claimed. Customer specifically acknowledges that CCS's price for the products is based upon the limitations of CCS's liability set forth herein.

©2009-2020 Continental Control Systems, LLC.
Document Number: WN-Inst-LON-2.21
Revision Date: March 17, 2020

Continental Control Systems, LLC
+1-303-444-7422, <https://ctlsys.com>

- WattNode is a registered trademark of Continental Control Systems, LLC.
- LonWorks, Echelon, Neuron, LonTalk, LON, LNS, and LonMaker are registered trademarks of Echelon Corporation.

(M6,M9)

Rev 2.21